




Daily Machine Activity & Agronomic Data

Export your point-by-point Daily Machine & Agronomic Activity in a CSV, Shapefile, or GeoJSON format.

Written By: Support





EXPORT MACHINE DATA

- Daily Machine Activity >
- Daily Machine Activity & Agronomic Data >

INTRODUCTION



- Provides daily point-by-point machine and agronomic data within the requested date range.
- Date range can be one or more days.
- Exporting from the grower level, will deliver data for all of your Farmobile PUC™ devices that had machine & agronomic activity within the requested date range.
- Exporting from a selected machine, will deliver data for only the selected device within the requested date range.
- All point-by-point exports follow these steps:
 - Request Export: Farmobile will begin processing the request and email you once ready.
 - Recieve Email: Farmobile will email you once the download is available. The link will take you to the Downloads page of Farmobile DataEngine platform.
 - Download File: Your requested data will be listed on the Downloads page from your account.

Step 1 — Select Machines from the Farmobile DataEngineSM Platform




- Selecting Machines from the Farmobile DataEngine account will open the Machines page with all of your Farmobile PUCTM devices listed and displayed on the map.

Step 2 — Select Export




- Selecting Export will open the Export Machine Data window.

Step 3 — Enter Details and Select Export




- Populate the date range, you can select a single day or multiple.
- Select Daily Machine Activity and Agronomic Data from the export type section.
- Check the box for each file format you want to export.
- Each file format requested will be delivered in separate compressed zip files.
- Once the data is ready, you'll receive an email from Farmobile.

Step 4 — Receive Email Notification



- Once the point-by-point data is ready, Farmobile will send you an email with the requested file name listed and a link to the Farmobile DataEngine account download page.
- At this point, your requested file is listed in the Download page.

Step 5 — Download the File



- Your file is listed in the Downloads page of Farmobile DataEngine platform.
- The list is sorted by date requested, so your most recent exports are listed at the top.
- Select download to download the zip file.